


Symptom:

External trigger cannot input into camera

< Confirmation >


(1) Check appropriate external trigger input type (TRIG1 or TRIG2).

※ Only J3 branched cable (Options) has TRIG2 connector.



Input Signal Settings	
External Trigger	TRIG1
Trigger Detection	Signal Level
TRIG1 Input	Nega
TRIG2 Input	Current ON
Set TRIG2 Filter as the same value as TRIG1	ON

(2) Check appropriate polarity of the external trigger signals.



Input Signal Settings	
External Trigger	TRIG1
Trigger Detection	Signal Level
TRIG1 Input	Nega
TRIG2 Input	Current ON
Set TRIG2 Filter as the same value as TRIG1	ON

(3) Check the external trigger signals output by the equipment are enabled.

(4) Check appropriate polarity of the external trigger signals output by the equipment.



If trouble cannot be solved after checking above confirmation list, please contact nac support team with following information.

- **Camera model and Serial Number (S/N)**