

Pre-Check List for Troubleshooting

- 1) What is model and Serial Number (S/N) of camera?
- 2) When was the last time the camera could shoot without any problem?

<Confirmation>

- (1) Check lens cap is off.
- (2) Set aperture of lens is open and turn the mount aperture ring of camera to open. after that, check shooting image.
- (3) Set low frame rate and exposure time on MLink. After that, check shooting image.
- (4) Remove the lens and check the mechanical shutter is not closed in front of the sensor.
- (5) Please perform Factory Reset. And check symptom will disappear or not. ✕ Please refer to another document ' How to perform factory Reset' on FAQ page.



If trouble cannot be solved after checking above confirmation list, please contact nac support team with following information.

- 2 items on 'Pre-Check List For Troubleshooting'