


# Ruler Display (Simple Measurement)


<Ruler type : Use Photo Info>

Ruler is displayed on live image and mcf file when putting information into lens magnification.



<Ruler type: Pixel>

Pixel information is displayed on ruler when putting pixel information in Ruler width (Pixel).



<Ruler type: Manual>

After clicking two points on image and putting distance information, ruler based on distance will be displayed.

